

R O  A N

# Kassel

By Heike Kruessel



# Kassel

by Heike Kruessel



## YARN

### All Seasons Chunky

2 x 100gm

(photographed in Heatwave 608)

## NEEDLES

Set of 4 double pointed 6mm (no 4) (US 10) needles

Set of 4 double pointed 7mm (no 2) (US 10½) needles

## TENSION

12 sts and 16 rows to 10 cm measured over patt using 7mm (US 10½) needles.

## FINISHED SIZE

Hat meas approx 25 cm (10 in) deep and has a circumference of approx 50 cm (19½ in).

## HAT

Using 6mm (US 10) needles cast on 64 sts.

Distribute sts evenly over 3 of the 4 needles, taking care not to twist cast on edge and using 4<sup>th</sup> needle, work in round as folls:

**Round 1:** \*K1, P1, rep from \* to end.

Place marker on needle to denote beg and end of rounds – marker 'sits' at centre back.

This round forms rib.

Cont in rib for a further 5 rounds.

Change to 7mm (US 10½) needles.

**Next round:** \*K4, M1, rep from \* to end. 80 sts.

Re-distribute sts over needles then work in patt as folls:

**Round 1:** \*K1, yfwd, sl 1, K1, pss0, K5, K2tog, yfwd, rep from \* to end.

**Round 2 and every foll alt round:** Knit.

**Round 3:** \*K2, yfwd, sl 1, K1, pss0, K3, K2tog, yfwd, K1, rep from \* to end.

**Round 5:** \*K3, yfwd, sl 1, K1, pss0, K1, K2tog, yfwd, K2, rep from \* to end.

**Round 7 :** \*K1, yfwd, sl 1, K1, pss0, K1, yfwd, sl 2, K1, p2sso, yfwd, K1, K2tog, yfwd, rep from \* to end.

**Rounds 8 to 19:** As rounds 2 to 7, twice.

**Rounds 20 to 24:** As rounds 2 to 6.

**Round 25:** \*K4, yfwd, sl2, K1, p2sso, yfwd, K3, rep from \* to end.

**Round 27:** \*K2, K2tog, yfwd, sl 2, K1, p2sso, yfwd, sl 1, K1, pss0, K1, rep from \* to end. 64 sts.

**Round 29:** \*K1, K2tog, yfwd, sl 2, K1, p2sso, yfwd, sl 1, K1, pss0, rep from \* to end. 48 sts.

**Round 31:** \*Sl 2, K1, p2sso, yfwd, rep from \* to end. 32 sts.

**Round 32:** \*K1, sl 2, K1, p2sso, rep from \* to end. 16 sts.

**Round 33:** \*Sl 1, K1, pss0, rep from \* to end. 8 sts.

Break yarn and thread through rem 8 sts, pull up tightly and fasten off.

## MAKING UP

Press as described on the information page.

To find your local stockist  
click here

To view the information  
guides click here